

DRIVEWAY CONSTRUCTION

- WHEN CONSTRUCTING DRIVEWAY WITH CONCRETE PAVEMENT, STOP CONCRETE AT EDGE OF SHOULDER AND PLACE BITUMINOUS PAVEMENT IN SHOULDER AREA
- WHEN PAVING DRIVEWAY PLACE MINIMUM 4" DEPTH OF PAVEMENT OR TO A DEPTH EXISTING PAVEMENT WITHIN THE DEPARTMENT RIGHT-OF-WAY.

